

Operating Instructions

Caring for your Scale

Clean the scale with a slightly damp cloth. Do not use a corrosive cleaner.

The scale is not waterproof. Do not immerse directly into water.

Do not attempt to dismantle the scale. It does not contain parts that may be repaired by the user.

Do not subject the scale to extreme temperatures.

Remove the battery if the scale is not being used for a long period of time.

Battery Warning

- KEEP OUT OF REACH OF CHILDREN.
- Batteries are harmful if swallowed.
- Non-rechargeable batteries are not to be recharged.
- Only batteries of the same or equivalent type are to be used.
- Batteries are to be inserted with the correct polarity.
- Remove exhausted batteries from the product.
- Remove batteries from the battery compartment when not in use.
- Never throw batteries in a fire or attempt to open up their outer casing.
- Dispose of old batteries responsibly.

Specifications

Capacity: 5000g / 176.4fl.oz / 11lb:0.4oz / 5000ml.

Graduation: 1g / 0.1fl.oz / 0.1oz / 1ml

Tare weigh function

Measures water volume in ml or fl.oz

Tempered Glass platform

Touch sensors

Auto Off

LCD with backlight

Battery: 2 x CR2032 Lithium (included)

Instructions for use

Remove all packaging before first using the scale.

Note: The insulator tab found underneath the battery in the battery compartment must be removed to activate the scale. If necessary, use a suitable tool to dislodge the battery compartment open.

FUNCTION KEYS

UNIT SELECTION
BUTTON




ON / OFF /
TARE BUTTON





1. Place the scale on a hard, level surface. If you intend using a bowl or container, place it on the platform first before switching it on.

2. To turn the scale on, press .

3. The full display appears for about 2 seconds before it 'zeros' indicating it is now ready for use.



4. Should you wish to change the unit measure, press the . The screen displays in the following sequence - ml...g...fl oz...lb/oz.

5. Place the object or ingredients directly onto the platform, or in the bowl or container placed securely on the platform. Ensure the scale readout shows zero before weighing, otherwise, press  to reset it.




To use the tare weighing function

This scale allows the separate weighing of items as they are added onto the scale. No need to empty the bowl or container!

1. After weighing the first item on the scale and with this first item still on the scale, press  to reset the display to zero. 'TARE' appears on the bottom left corner of the screen confirming this mode.
2. Add the second item to the scale. The scale will now display the weight of the second item only.
3. If you have additional items to weigh, repeat Steps 1. and 2. The total weight of all the items on the scale, (including the bowl or container if using one), must not exceed the capacity of the scale, which is 5000g / 176.4fl.oz / 11lb:0.4oz / 5000ml.
4. The total weight of the items on the scale, (including the container or bowl if using one), can be obtained by first pressing , then removing all items from the scale. The total weight will be displayed as a minus figure.

To turn the scale off

Turn the scale off at any time by holding down  for approximately 3 seconds. If left idle, the scale will switch off automatically after approximately 60 seconds.

Overloading

If the scale is overloaded, 'EEEE' will be displayed. Remove the weight immediately or damage to the scale may occur.

Low battery indicator



The low battery symbol will appear on the readout indicating the batteries need to be changed. Replace the batteries with fresh, good quality lithium ones, making sure the '+' symbols on both are facing up.