

# Surpahs™ STT-801 Digital Bathroom Scale User Manual

The user manual can be downloaded through Surpahs™ website at <http://www.surpahs.com>



Scan for shopping and support:



Surpahs™  
[www.surpahs.com](http://www.surpahs.com)

## FEATURES & PECIFICATIONS

---

- Step-ON
- Equipped with 4 high precision sensors
- Display: 3.5" Large Backlit LCD
- Capacity: Min. 11 lb/5 kg - Max. 400 lb/180 kg
- Graduation: 0.1kg ; 0.2 lb ; 0.2 lb/1 lb ( $\geq 20$ st)
- Weight Units: lb, kg, st:lb
- Power Supply: 4 x AAA batteries
- Auto-OFF Time: 8 Seconds of Non-Operation
- Low battery indication: "Lo"
- Overload Indication: "----"

## BATTERIES

---

- Uses 4 x AAA batteries
- Make sure the + and – sides of the batteries are aligned correctly.
- Replace batteries when the low battery indicator is shown.

## OPERATION INSTRUCTION

---

### I. Weighing

- a) Place the scale on hard flat even surface for accurate readings.
- b) Stand on the scale, it will turn on and measure your weight.

### II. UNIT Selection

- To change measuring units, turn the scale upside down and press the Unit button until the desired unit is selected.
- You can choose Kilos (kg), Pounds (lbs) or Stones (st)

### III. Turning Off

The screen will turn off in about 8 seconds, and machine will turn off in about 60 seconds of no use.

## MAINTENANCE AND CARE

---

- Please use the scale on a flat, level and hard surface free from vibration and drafts, use it at room temperature.
- If the scale is not to being used for a long period, please remove the batteries,
- Clean the scale with a slightly damp cloth, do NOT immerse the scale body in water or use chemical/abrasive cleaning agents.
- Check the batteries first if you are having any trouble with your scale. This simple step can remedy most scale issues.

## WARRANTY

---

This product is warranted against defects in materials and workmanship for one year from the date purchase, when used in accordance with the instructions provided. This warranty does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair.

C8KE INC. shall not be liable for loss of use or any other incidental, consequential or indirect costs, expenses or damages. There are no express warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

Should this product require service (or replacement at our option) while under warranty, please visit website [www.surpahs.com](http://www.surpahs.com) and submit a support ticket.

## SUPPORT

---

If you have any questions about this product, please visit [www.surpahs.com](http://www.surpahs.com), or scan the QR code, find the support link.

Surpahs™, C8KE INC.  
DE 19809, USA